

Facilitated installation of the E2019L and E1684L air filter elements by using assembly paste

To fit the E2019L/E540LS and E1684L/E1684LS air filter elements in the air filter housing, it is necessary to use assembly paste. The assembly paste must be applied to the inner and outer sides of the safety inserts and only to the inner side of the main elements. It is important that the safety and main air filter elements reach the end position during mounting in the housing so that the housing cover can be closed without problems.



E2019L



E540LS



E1684L



E1684LS

The assembly paste not only helps to insert the filter elements with a precise fit, so that the filters are easier to mount, but also has the advantage that the subsequent removal of the elements can be significantly simplified.